

Function

This is a piece of equipment with the typical push and pull movements of sawing. It promotes movement and strengthening of the arms and shoulders. It is possible to hold with one or both hands; furthermore sawing can be done individually or with a partner. Angling the saw up or down also allows it to be used in different positions.




Copyright © Richter Spielgeräte GmbH 07/14

Design M. Linacisoro

Saw



11.01200



Technical information

Core-free timber

sawn-timbers of mountain larch, selected according to eight quality criteria, core-free thus decreasing the occurrence of cracking



Adjustable

no projecting threads after re-tightening due to two-piece bolt connection and therefore easy to maintain



Ground anchor

foundation anchor made of phenol resin paper based laminate



sandwich construction frame, oiled, non-positive fitting

saw made of stainless steel

handle balls made of polyamide

Dimensions

(small deviations possible)

height 1.10 m
width 0.90 m
depth 0.35 m
saw deflection 0.50 m max.

weight approx. 80 kg

For more detailed explanation of the quality characteristics see price list.

Components

1 complete saw including 2 foundation anchors

Installation information

Surfacing no requirements

Foundations
1 item 60 x 70 x 40 cm
excavation depth 60 cm

Attention!

Exact measurements may vary, for all installation dimensions refer to current installation instructions.
Subject to technical changes!

Safety

This equipment is not playground equipment within the scope of EN 1176 and therefore is also not subject to the requirements of this standard. Nevertheless, it is complied with where appropriate.



11.01200