Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of	
Checks depend on the type of equipment.	cracks.	
Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	Check that all bolts and screws are tight and retighten if necessary.	
Intervals for maintenance work and checks generally depend on	3. <b>Recommendation</b> : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.	
- location	Boat suspension	
<ul><li>usage</li><li>frequency of use</li><li>possible vandalism</li></ul> For more details see also our general	4. Check that bearings move smoothly in both directions and check for wear and tear. Replace if necessary.  Attention: The movements occurring during use of the equipment may cause	
instructions for maintenance of playgrounds!  Sailing Boat	premature wear on one side of the bearing bushings of the square block steel. This may result in damage to or breakage of the square block steel. These parts must be checked with great care by loosening the bolts; replace if necessary.	
Order No. 6.03200 with Flag	<ul><li>5. Check connection to wood; the tie joint</li></ul>	
Order No. 6.03210 without Flag	must fit closely (see detailed diagram).	
Sailing Boat with steel posts Order No. 6.03201 with Flag Order No. 6.03211 without Flag	6. Check chain and connection to chain; The first chain link must be locked; check wear on contact surfaces between first and second chain link (see detailed diagram).	
< 1 8	Mast chains	
(3) (7) (4) (4) (4) (5)	<ul><li>7. Chains must be taut, re-tension if necessary.</li><li>8. Check the upper attachment of the chains on the mast for wear.</li></ul>	e.g. for repairs
	Structural stability	y. for r
40 cm Check clearance to the ground with no load placed on	9. Uncover the foundation once a year in order to check for rot or respectively the steel stand posts for corrosion.	Special notes, e.g
the equipment.  detailed diagram	Repair not carried out, it is still possible to play on equipment	
tie joint (5)	Repair not carried out, equipment is taken out of action	
The first first chain link must 6 square block steel	All work carried out, everything is in order	
be locked.	Maintenance carried out by:	
For spare parts refer to next page.	Date	

Page 2 Please note that the safety standards of the equipment **Spare parts** must not be affected. Therefore, when carrying out Sailing Boat repairs it is helpful to only use original parts. Order No. 6.03200 / 6.03201 / 6.03210 / 6.03211 Order No. Spare parts 99.01263 Mast with chain guide and mast support 99.01248 Mast with chain guide without mast support 0.92310 **Joint** 0.88190 Square block steel with 2 brass bushes 0.88160 Brass bush for square block steel